

Original Instructions

Installation Operations and Maintenance manual

SXH/HP series

Incorporated in this manual there are the following documents:

- Declaration of conformity
- Technical schedule
- Dimensional drawing
- Wiring diagrams

Dear customer,

We thank you for purchasing a VORTICE INDUSTRIAL product,

manufactured with first choice materials and advanced technologies.

The quality level is under constant control, and VORTICE INDUSTRIAL products are therefore synonymous with Safety, Quality and Reliability.



Multiple instructions:
Consult the specific part



Read and understand
the instructions before
undertaking any work on
the unit

The Company have the right to introduce at any time whatever modifications necessary to the improvement of the product.

Reproduction, data storage and transmission, even partial, of this publication, in any form, without the prior written authorisation of Vortice Industrial S.r.l., is prohibited. Vortice Industrial S.r.l. can be contacted for all inquiries regarding the use of its products.

Vortice Industrial S.r.l. follows a policy of continuous product development and improvement and reserves the right to modify specifications, equipment and instructions regarding use and maintenance at any time, without notice.

Declaration of conformity

We declare under our own responsibility that the units and the equipment complies in all parts with the CEE and EN directives. The CE declaration of conformity is enclosed to the technical schedule enclosed with the unit.



The unit is equipped with a series of prevention and safety devices described in detail in the accompanying documentation. The installer is required to connect and activate all these mounted components, checking their functionality.



The system or machine into which this unit is to be incorporated must also comply with the above mentioned Directives. The user, or whoever subsequently operates the system, must periodically check the functionality and efficiency of the safety devices.



The non-activation, removal or inhibition of the active safety systems, as well as the removal of the passive safety systems, exempt Vortice Industrial s.r.l. from any responsibility regarding any accident or damage, direct or indirect, to people and/or things, attributable to the machine.



The manual supplied with the unit is completed by a TECHNICAL DATA SHEET, with the fundamental constructive and functional data, and by the relative DRAWINGS.



Transport, handling, installation and subsequent operation must be carried out in full compliance with the above prescriptions, in the subsequent indications of the manual and the accompanying documentation.

GENERAL INDEX

1. INTRODUCTION	06
1.1 General information	06
1.2 Purpose and Content of the Instructions	06
1.3 Storage of instructions	06
1.4 Instructions update	06
1.5 How to use these instructions	06
1.6 Residual Risks	07
1.7 General Safety Symbols	09
1.8 Safety Symbols	10
1.9 Limits of use and prohibited uses	11
1.10 Unit identification	11
2. TECHNICAL CHARACTERISTICS	12
2.1 Introduction	12
2.2 Structure	12
2.3 Heat recovery (1° recovery stage)	12
2.4 Heat pump refrigerant circuit (2° recovery stage)	13
2.5 Electric box	13
2.6 Control system	13
2.7 Air filters	13
2.8 Fans	13
2.9 Test	14
2.10 Packing	14
3. CONFIGURATIONS	14
4. MAIN COMPONENTS OF THE UNIT	15
5. AVAILABLE ACCESSORIES	16
6. OPERATING MODE	17
6.1 Start-Up mode or Night heating mode	17
6.2 Dehumidification mode with "ALPHA" cycle	17
6.3 Dehumidification mode with fresh air	17
7. TECHNICAL DATA	18
8. VENTILATION CURVES	19
9. OPERATING LIMITS	21
10. SOUND DATA	22
10.1 Noise levels	22
10.2 Sound attenuators reduction	22
11. SAFETY AND CONTROL DEVICES	23
12. INSTALLATION	24
12.1 Receipt and inspection	25
12.2 Storage	25
12.3 Unpacking	25
12.4 Lifting and Handling	26
12.5 Positioning	27
12.5.1 Preliminary notice	27
12.5.2 Service area requirements	29
12.6 Section coupling and bolting	29
12.7 Hydronic connections	31
12.8 Hydraulic connection to the exchange water coils	31
12.9 Connecting the unit to air ducts	32

13. MODBUS-RS485 / BACnet SERIAL INTERFACE CARD.....	32
14. FILTERS and HEAT EXCHANGER EXTRACTION	33
15. REFRIGERANT DIAGRAM.....	34
15.1 Refrigerant circuit with 1 compressor.....	34
15.2 Refrigerant circuit with 2 compressors	35
16. ELECTRICAL CONNECTIONS.....	36
16.1 Electrical data	37
16.2 Power supply connection	37
16.3 Terminal Block Connections	38
16.4 Connections on main board.....	39
16.5 Description of the remotable control panel	39
16.5.1 Position of the control panel.....	39
16.5.2 Remote panel keys	39
16.5.3 Dimensions.....	40
16.5.4 Wall installation	40
16.5.5 Electrical connection	41
17. STARTUP.....	41
17.1 Preliminary checks	41
17.2 Checks during the operation.....	42
18. UNIT USE.....	43
18.1 Function of display icons.....	43
18.2 Factory default settings	43
18.3 Switching on and parameters setting	44
18.4 Enabling time bands.....	48
19. CONTROLS.....	50
19.1 Fans.....	50
19.2 Adjusting dampers.....	51
19.2.1 Alpha cycle damper.....	51
19.2.2 Recirculation Damper.....	51
19.3 Pool request controls	52
20. DIAGNOSIS AND TROUBLESHOOTING	53
20.1 Troubleshooting.....	53
21. DIMENSIONAL DRAWINGS.....	56
22. UNIT MAINTENANCE	58
22.1 General warnings	58
22.2 Access to the unit.....	58
22.3 Periodical checks	59
22.4 Refrigeration circuit repair	59
23. DISMANTLEMENT, MATERIALS' DISPOSAL AND RECYCLING.....	60
23.1 Unit disconnection	60
23.2 RAEE Directive (EU only)	61

1. INTRODUCTION

Units must be installed and operated according to the instructions in this manual. Strict adherence to these simple instructions is a prerequisite to:

- eliminate or reduce shutdown time due to unexpected failures;
- improve the performance of components, resulting in energy savings;
- increase the life of components and the entire unit;
- decrease maintenance costs.

1.1 General information

This manual has been prepared to allow correct installation, set-up and maintenance of the unit. Any contractual or extra-contractual responsibility of the Company for damage caused to persons, animals or things, due to installation, adjustment and maintenance errors or improper use, is excluded. Any use other than that specified does not imply for the manufacturer any commitment or obligation of any kind.

This documentation is an informative support and cannot be considered as a contract towards third parties.

The Company implements a policy of constant improvement and development of its products. It therefore reserves the right to make changes to specifications, fittings and documentation at any time, without prior notice and without any obligation to update what has already been delivered.

1.2 Purpose and Content of the Instructions

These instructions provide essential information for the installation, operation, testing and maintenance of the machine. They have been drawn up in accordance with the legal provisions issued by the European Union and the technical standards in force at the time the instructions were issued.

The local safety regulations in force at the time of installation must be observed.

The instructions contain instructions for avoiding reasonably foreseeable misuse.

1.3 Storage of instructions

This manual and the eventual wiring diagram of the unit must be carefully stored in a suitable place, protected from dust and humidity and easily accessible to users and operators for any further consultation.

The instructions must always follow the unit throughout its entire life cycle and must therefore be passed on to any subsequent user.

1.4 Instructions update

It is recommended to check that the instructions are up to date with the latest revision available.

Any updates sent to the customer should be retained as an attachment to this manual.

The Company is available to provide any information regarding the use of its products.

1.5 How to use these instructions



The instructions are an integral part of the unit.

It is compulsory for users or operators to consult the instructions before any operation on the unit and on any occasion of uncertainty regarding the transport, handling, installation, maintenance, use and dismantling of the unit.

In these instructions, in order to draw the attention of operators and users to the operations to be carried out in safety, graphic symbols have been included that are shown in the following paragraphs.

1.6 Residual Risks

A residual risk is any hazard that cannot be fully reduced by design and protective techniques, or a potential hazard that is not obvious.



ATTENTION

This manual indicates any operation that may generate a hazardous situation as well as the precautionary measures to be observed in each case.

- All units have pictograms with hazard warnings.
- The units are safe machines, provided the safety guards are not tampered with or removed.
- Technical preparation, observance of the procedures outlined in this manual, and markings at critical points on the unit will still allow safe operation.
- The following safety rules must be observed during installation, start-up, use and maintenance of the units:



- Do not operate the unit unless it and its electrical components have been connected to the earthing system;
- Do not operate unit unless fan is connected to a duct or protected with safety mesh;
- Do not use the unit as a stand for other machinery;
- Do not use unit as a walkway;
- Do not use unit as equipment storage;
- Do not open inspection panels while fan is running, especially in over pressure sections;
- Do not leave inspection panels partially closed; Make sure all handles or knobs are securely closed;



- Wear personal protective equipment before working on the unit;



- Before accessing the unit, make sure that all electrical utilities have been turned off, especially before opening the inspection panels, make sure that the fan is off and cannot be turned on again without the knowledge of the person working on the unit;



- Before starting the fan, always refit the protection cover or the closing panel of the fan section;



- Be careful when lifting the unit as its center of gravity may be severely unbalanced;
- Be careful when locking the lifting ropes/hooks;
- Be careful of sheet metal edges inside the unit;
- Be careful of sheet metal edges outside the unit;
- Be aware of possible burns from heating coils;
- Be aware of dampers that may close unexpectedly.

Whilst the unit has been designed to minimize any risk posed to the safety of people who will interact with it. It has not been technically possible to eliminate completely the causes of risk. It is therefore necessary to refer to the requirements and symbolism below.

LOCATION OF RISK (if present)	RESIDUAL RISK	METHOD OF INJURY	PRECAUTIONS AND PROTECTIONS
Mixing box with dampers and actuators	Crush	Contact	Remove voltage before any operation
Thermal heat exchangers	Small stab wounds, burns	Contact	Avoid any contact, use protective gloves
Electric heaters	Electrocution, severe burns	Contact, Fire due to short circuit or overheating of the heating elements	Periodic check of the safety devices, adhesive warning signs on the machine
Heat exchangers	Small stab wounds, crush	Contact	Avoid any contact, use protective gloves
Fans	Cuts, eye damage, broken bones	Insertion of objects through the fans are operating	Never put objects through the fans sections
External to unit: unit enclosure	Intoxication, severe burns	Fire due to short circuit or overheating of the supply cable external to unit	Size cables and mains protection system in accordance with standards regulations
Inside the unit: compressors and gas supply pipes	Severe burns	Contact	Avoid any contact, use protective gloves
Internal component: electric cables and metallic parts	Electrocution, severe burns	Defect in the supply cable insulation, live metallic parts	Adequate protection of power cables, ensure correct earthing of all metal parts
Low pressure safety valves	Intoxication, severe burns	Elevate evaporating pressure not suitable for correct operation of the unit during the maintenance operations	Carefully check the evaporating pressure during the maintenance operations
High pressure safety valves	Intoxication, severe burns, hearing loss	Intervention of the high pressure safety valve with open refrigerant circuit cabinet	Avoid, as much as possible, the opening of the refrigerant circuit cabinet; carefully check the condensing pressure value; use all protection devices as indicated by regulations in force

1.7 General Safety Symbols

Individual safety symbols in accordance with ISO 3864-2:



PROHIBITION

A black symbol inserted in a red circle with a red diagonal indicates an action that must not be performed.



WARNING

A black graphic symbol within a yellow triangle with black borders indicates a hazard.



MANDATORY ACTION

A white symbol inserted in a blue circle indicates an action that must be performed to avoid a hazard.

Combined safety symbols in accordance with ISO 3864-2:



The graphic symbol “warning” is qualified with additional safety information (text or other symbols).

1.8 Safety Symbols



GENERAL DANGER

Strictly observe all indications placed beside the pictogram. Failure to observe the indications may lead to situations of risk with possible consequent damage to the health of the operator and the user in general.



ELECTRICAL HAZARD

Observe all signs placed next to the pictogram. The symbol indicates components of the unit and actions described in this manual that could create an electrical hazard.



MOVING PARTS

The symbol indicates those moving parts of the unit that could create risk.



SHARP SURFACES

The symbol indicates components or parts that could cause stab wounds.



HOT SURFACES

The symbol indicates components of the unit at elevated surface temperature which might create risk.



EARTH CONNECTION

The symbol identifies earthing connection points in the unit.



READ AND UNDERSTAND THE INSTRUCTIONS

Read and understand the instructions of the machine before any operations.



RECOVER OR RECYCLE MATERIAL

1.9 Limits of use and prohibited uses

The machine has been designed and built exclusively for the uses described in the technical manual. Any other use is prohibited as it could generate health risks for the operators and users.



However, the unit is not suitable for operation in environments:

- where vibrations are present;
- where electromagnetic fields are present;
- where aggressive atmospheres are present.





THIS UNIT IS NOT SUITABLE FOR OPERATION IN EXPLOSIVE ATMOSPHERE.

1.10 Unit identification

Each unit has a label attached to the outside of the unit, which shows the identification data of the machine together with the main technical characteristics.

For electrical information not included on the label, refer to the electrical diagram.

Check that the characteristics of the electrical network comply with the data on the identification plate.

VORTICE INDUSTRIAL		VORTICE INDUSTRIAL S.R.L. via Bernardino Brugnoti, 3 37063 Isola della Scala Verona (Italy) - Tel. +39-045 6631042		 vorticeindustrial.com	
Range / Type	1	Year of manufacturing	8		
Serial number	2	Operating weight	9	kg	
Power supply (V/Hz/ph)	3	Max. current input	10	A	
Refrigerant type GWP	4	Auxiliary voltage	11		
Electric diagram n°	5	Electric power supply fan	12	kW	
Refrigerant Charge	C1 C2 6a 6b	kg	Electric power return fan	13	kW
CO2 eq.	7	t eq	Electric power compressors	C1 C2 14a 14b	kW
LOW PRESSURE SIDE			HIGH PRESSURE SIDE		
Working pressure	15	bar	Working pressure	19	bar
Working temperature	16	°C	Max design pressure	20	bar
Min design temperature	17	°C	Min design temperature	21	°C
Max design temperature	18	°C	Max design temperature	22	°C
			Max design temperature	23	°C
			Safety pressure	24	bar
MADE IN ITALY "Hermetically sealed equipment. It contains fluorinated greenhouse gases covered by the Kyoto protocol"			 0426		

CAPTION:

- (1) Unit model and size
- (2) Serial number
- (3) Power supply characteristics
- (4) Type of refrigerant
- (5) Wiring diagram number
- (6a-6b) Refrigerant content in the circuits 1 & 2
- (7) CO₂ equivalents
- (8) Manufactured year
- (9) Overall unit weight
- (10) Max. electric current consumption
- (11) Auxiliary voltage
- (12) Electric power input on supply fan
- (13) Electric power input on exhaust fan
- (14a-14b) Electric power input on circ. 1 & 2 compressors
- (15) Working pressure (low pressure side)
- (16) Working temperature (low pressure side)
- (17) Min design temperature (low pressure side)
- (18) Max design temperature (low pressure side)
- (19) Working pressure (high pressure side)
- (20) Max design pressure (high pressure side)
- (21) Min design temperature (high pressure side)
- (22) Max design temp. (gas) (high pressure side)
- (23) Max design temp. (liquid) (high pressure side)
- (24) Safety pressure (high pressure side)

In all dealings with the Company it's essential to quote the model and serial number indicated on this plate (ref. 1 and 2).



The identification label must never be removed from the unit.

2. TECHNICAL CHARACTERISTICS

2.1 Introduction

Public indoor swimming pools are generally characterised by an air temperature between 28 °C and 33 °C, in order to offer bathers a comfortable environment. In principle, the air temperature in the pool rooms is almost always warmer than the outside air. These rooms are also characterised by a high degree of water evaporation which leads to a high level of humidity and an unpleasant feeling of oppressive heat.

If humidity is not controlled, not only is the time spent in an indoor pool perceived as unpleasant, but the climate that forms in the environment can also cause real discomfort to the users and the public present. In addition, there is a risk that the moisture contained in the water vapour condenses on colder surfaces, such as metal components, external walls or glass surfaces.

This can lead to the formation of mould and can cause corrosion. If all this were to occur, the building would suffer considerable damage over time, which would lead to costly renovation work, accompanied by business interruptions and economic losses for the site manager. In these applications, room ventilation is mandatory and is strictly regulated by specific international regulations. Ventilation, however, involves considerable energy consumption, and good heat recovery systems combined with advanced control systems must be used to manage it.

The most important aspect of ventilation systems in a public indoor swimming pool are not the investment costs, but the operating costs, for this reason the correct choice of the air handling unit can lead to very important savings in the long term and a recovery of costs in a very short time.

2.2 Structure

The structure of the units can be realized in two versions:

VERSION 1:

Profiles 50 x 50 mm in self-supporting extruded anodized aluminium, with mechanical strength requirements in accordance with EN 1886: D1 (M). 50 mm thick double-wall sandwich type paneling with both exterior and interior side in pre-painted RAL 9010 galvanized sheet steel with interposed insulation made of polyurethane foam with a density of 40 kg/m³.

This structure has a seal class L1 while the thermal transmittance and the thermal bridge characteristic is class T3/TB4 according to EN1886.

VERSION 2:

Thermal break profiles 60 x 60 mm in self-supporting extruded anodized aluminium, with mechanical strength requirements in accordance with EN 1886: D1 (M). 63 mm thermal break sandwich-type double-walled sandwich-type panels with both exterior and interior side in pre-painted RAL 9010 galvanized sheet steel with interposed insulation made of polyurethane foam with a density of 40 kg/m³. This structure has a seal class L1 while the thermal transmittance and the thermal bridge characteristic is class T2/TB2 according to EN1886.



The units are supplied as standard in a MONOBLOCK configuration, in case of multi-section units, they are available in special execution. Please contact the Company for further details.

2.3 Heat recovery (1° recovery stage)

The units are equipped with a counter-flow heat exchanger painted used in cooling/heating mode to transfer the heat from the exhaust air to the inlet fresh air. The heat exchange is counter-flow with efficiencies higher than 80%. The spacing between the fins is optimized in order to reduce the pressure drop on the air side and the electrical consumption of the fan. Under certain conditions of low outside air temperature and high humidity, the heat recovery may start to frost.

Through the integrated control system it is possible to manage the defrosting of the heat recovery by activating different stages of electrical resistances (pre-heaters), or by activating the recirculation damper. The heat recovery is also equipped with an additional by-pass damper for the management of the free-cooling and free-heating mode.

2.4 Heat pump refrigerant circuit (2° recovery stage)

The efficiency of the unit is further increased thanks to a second phase of indirect recovery, obtained through a heat pump refrigeration circuit compression system. The cooling circuit is equipped with a Scroll type compressor with inverter, with continuous capacity regulation. The compressor is complete with thermal protection, crankcase heater, low and high pressure switches and vibration isolators suitable to isolate vibrations.

The refrigerant circuit is of direct expansion type loaded with R410A refrigerant. Each refrigerant circuit is factory tested both in terms of tightness (pressure test) and functionality. The main components are: finned pack heat exchangers and source, electronic expansion devices, solid-cartridge anti-acid filters, safety pressure switches on high and low refrigerant pressure side, receiver and liquid separator on suction side, liquid / humidity sight glass, cycle reversal valve, non-return valves, safety valves on high pressure side.

The circuit is complete with reverse cycle defrosting system and a fresh air by-pass.

2.5 Electric box

The electric box is manufactured according to IEC 204-I / EN 60204-I standards and complete with door block disconnector, CE insulation transformer. All motors and auxiliary circuits are protected against overload and short circuits by fuses and/or circuit breakers. The electrical panel also includes the following components: General alarm contact, remote control ON/OFF, summer/winter seasonal changeover contact, outdoor air temperature probe, supply air temperature probe, return air temperature probe, recirculation air probe, defrost recovery probe, source exchanger defrost probe, pressure switches for supply and return dirty filters.

2.6 Control system

The unit is complete with adjustment by means of a microprocessor electronic board with dedicated software and external LCD display as user interface. Through the external or remote LCD display it is possible to set all the working set-points of the unit and to visualize the operating states and possible alarm conditions present.

The unit is equipped with a microprocessor control system, able to manage the different operating modes, ensuring maximum energy saving in all conditions of use.

The electronic controls, according to the needs of the environment, can operate in different modes such as:

- dehumidification with external air;
- dehumidification with Alpha cycle;
- heating with external air;
- recirculation heating;
- activation of pool water heat recovery.

The microprocessor also activates and modulates all the dampers of the unit and optimizes all the operating parameters of the refrigerant circuit. The RS485 interface is standard (MODBUS protocol) to be used for connection to remote supervision and control systems. The control can also be supplied with remote control panel (optional).

2.7 Air filters

ePM₁ 55% (F7) filters on return air and fresh air inlet. The filters are mounted on slides equipped with gaskets to ensure effective sealing. Their position, upstream of the internal components, also guarantees their protection.

2.8 Fans

The units are equipped with high efficiency plug-fan type fans with built-in brushless EC motor. In this way it is possible to guarantee an accurate regulation of the airflow both in the supply and extract section, ensuring that all regulatory requirements such as SFP are met with. The airflow rate of the fan is managed through the integrated electronic control system thus ensuring, according to the needs of the system, that the correct operation of the unit is maintained with consequent saving of the energy absorbed by the unit. The fans are fixed to the frame by means of selfcentering brackets to ensure the correct distance between the impeller and the nozzle, thus optimizing performance.



2.9 Test

Units are fully assembled and wired at the factory and subjected to a complete functional test before shipment. They are manufactured in compliance with the safety standard of the Machinery Directive 2006/42/EC, the Low Voltage Directive 2006/95/EC, and the Electromagnetic Compatibility Directive 2004/108/EC and therefore complies with the "Health and safety requirements" prescribed. Units are provided with CE markings, certificate of conformity, user and maintenance manual.


2.10 Packing

Units are supplied on thick wooden feet and wrapped in plastic film to protect against impacts during transport and handling on site.

3. CONFIGURATIONS



4. MAIN COMPONENTS OF THE UNIT



1	Return air filter	9	By-Pass damper on heat exchanger
2	Backward blade fan, EC brushless motor with external rotor (exhaust side)	10	Heat pump user exchanger
3	Recirculation damper	11	Backward blade fan, EC brushless motor with external rotor (supply side)
4	Counterflow heat exchanger	12	Compressori con inverter completi di circuito frigorifero in pompa di calore
5	Heat pump source exchanger	13	Electrical panel
6	Alpha cycle damper	14	Microprocessor control panel with LCD display
7	Air damper with actuator ⁽¹⁾		
8	Fresh air inlet filter		

⁽¹⁾ component supplied on request as an accessory

5. AVAILABLE ACCESSORIES

Return / Supply side ePM₁₀ 50% (G4) air pre-filter

Made of galvanized steel sheet frame and undulated filter media, 48mm thickness, in white synthetic material, contained by two welded galvanized nets. The filter media has a low pressure drop and it may be installed as pre-filter in combination with the ePM₁₀ 60% (M5), ePM₁ 55% (F7) or ePM₁ 80% (F9) filters, located on the room air return side and/or supply air side.

Return / Supply side ePM₁ 55% (F7) air filter

Built with a polyester frame and a rigid bag filter media, thickness 292 mm, made of white glass microfibre. The filter media has an ePM₁ 55% (F7) filtering degree, according to ISO 16890 and has a large filtering surface area that guarantees long operating life and less frequent replacements.

Electric pre-heating coil

All units may be equipped with an internal pre-heating electric coil, made up of armoured steel electric heaters, supplied complete with PWM control system, safety thermostat already wired and installed on board.

Hot water coil

The hot water coil is manufactured with copper pipes thickness 0,4 mm and aluminium fins thickness 0,11 mm. The pipes are mechanically expanded in the aluminium fins to increase the thermal exchange rate.

Air damper with actuator

This is installed on board the unit and operate to exclude the fresh air intake and/or the room return air flow. This option is particularly useful in areas with very cold winter temperatures, where it is necessary to avoid dangerous self-induced cold air flows by the installation itself, during the stand-by period of the unit, with the risk of freezing the water contained in the water coils, if any. The damper is controlled by On/Off actuator for the opening or the closing, or with return closing spring.

Roof for outdoor installation

Flat roof rainproof for outdoor execution, made of pre-painted sheet metal.

45° hood with bird-trap

Rain hood with 45° angle for outdoor execution, to be applied in fresh air inlet or exhaust air, complete with bird-trap net.

Remotable control panel

All units are supplied as standard with a microprocessor control panel with high-resolution display, installed on board the unit. It is possible, however, to install a second control panel remotable up to 50 m away.

BACnet interface

Communication protocol BACnet for building automation and control (BAC) networks that use the ASHRAE, ANSI, and ISO 16484-5 standards protocol.

Flexible joint

Flexible joint for rectangular ducts, complete with galvanized steel flange.

Sound attenuator on return / supply side

The sound attenuator is supplied in a dedicated section external to the base unit, with the same sizes and features of the main unit, to be fixed using an installation kit supplied with it.

The sound attenuator baffles are made of mineral wool, thickness 100/200 mm, density 90 kg/m³, protected by a fabric veil that prevents any risk of fraying of the mineral wool even at high air velocities.


The mineral wool is contained in a galvanised frame with a galvanised steel microstretched retaining mesh.

The sound-absorbing material is class M0.

6. OPERATING MODE

6.1 Start-Up mode or Night heating mode


The unit operates in 100% recirculation mode without external air supply. The air in the pool room is recirculated and heated by the water coil in the unit and supplied by an external energy source (e.g. boiler). The heat pump circuit is in stand-by. The fans operate in flow modulation to minimize the power consumption of the unit.



6.2 Dehumidification mode with "ALPHA" cycle


The unit operates with the minimum amount of fresh air to ensure the hygiene requirements of the pool room. In this mode, the fresh air is sufficient to ensure adequate dehumidification of the room, if this is not sufficient, part of the air downstream of the heat pump evaporator (dehumidified) is recirculated to supplement the dehumidification.

In this way a percentage (variable) of the airflow is expelled, fully integrated with fresh air. The fresh air is pre-heated in the heat recovery and then in the condenser of the heat pump; in case the temperature is not yet warm enough, it will be integrated with the hot water coil.



6.3 Dehumidification mode with fresh air

The unit operates with 100% fresh air. The by-pass damper on the heat recovery pack of the cross-flow heat recovery is closed and the unit operates by heating all the fresh air. Dehumidification takes place using fresh air. The heat pump circuit recovers the energy expelled from the room and heats the supply air.



7. TECHNICAL DATA

MODEL		021	031	041	061	081
Nominal airflow rate	m ³ /h	2000	3000	4500	6000	8000
External air flow	%	0 ÷ 100	0 ÷ 100	0 ÷ 100	0 ÷ 100	0 ÷ 100
Thermal efficiency recovery ⁽¹⁾	%	79,5	78,9	79,9	79,7	79,4
Thermal power recovery ⁽¹⁾	kW	16,3	24,4	37,1	49,6	65,9
Thermal power of refrigerant circuit ⁽¹⁾	kW	8,5	14,2	20,0	28,1	34,3
Total thermal power of unit ⁽¹⁾	kW	24,8	38,6	57,1	77,7	100,2
Electrical power absorbed of compressor ⁽¹⁾	kW	1,2	1,7	2,0	3,5	4,7
Electrical power absorbed of supply fans	kW	0,65	0,94	1,44	1,93	2,70
Electrical power absorbed of return fans	kW	0,57	0,85	1,31	1,74	2,44
Total electrical power absorbed ⁽¹⁾	kW	2,42	3,49	4,75	7,17	9,84
COP refrigerant circuit ⁽¹⁾	W/W	4,4	4,3	4,3	4,4	4,2
SFP factor ⁽³⁾	W/(l/s)	1,54	1,56	1,68	1,67	1,76
Supply fan available static pressure	Pa	350	350	350	350	350
Return fan available static pressure	Pa	300	300	300	300	300
Thermal power of water coil ^{(1) (2)}	kW	23,6	35,1	49,3	67,1	90,2
Number of compressors: inverter	n°	1	1	1	1	1
Number of refrigerant circuits	n°	1	1	1	1	1
Type of refrigerant		R410A				
Energy classification filters		ePM1 65% (F7)				
Power supply	V/ph/Hz	400/3/ 50				

MODEL		101	132	172	242
Nominal airflow rate	m ³ /h	10000	13000	17000	24000
External air flow	%	0 ÷ 100	0 ÷ 100	0 ÷ 100	0 ÷ 100
Thermal efficiency recovery ⁽¹⁾	%	79,3	80,0	79,5	78,3
Thermal power recovery ⁽¹⁾	kW	81,5	106,0	140,6	181,6
Thermal power of refrigerant circuit ⁽¹⁾	kW	43,2	64,1	80,7	104,0
Total thermal power of unit ⁽¹⁾	kW	124,7	170,1	221,3	285,6
Electrical power absorbed of compressor ⁽¹⁾	kW	5,8	8,2	9,5	16,0
Electrical power absorbed of supply fans	kW	3,29	4,03	5,51	8,14
Electrical power absorbed of return fans	kW	2,92	3,65	4,98	7,45
Total electrical power absorbed ⁽¹⁾	kW	12,01	15,88	19,99	31,59
COP refrigerant circuit ⁽¹⁾	W/W	4,3	4,5	4,4	4,5
SFP factor ⁽³⁾	W/(l/s)	1,68	1,61	1,69	1,84
Supply fan available static pressure	Pa	350	350	350	350
Return fan available static pressure	Pa	300	300	300	300
Thermal power of water coil ^{(1) (2)}	kW	113,5	136,1	183,3	248,0
Number of compressors: inverter	n°	1	1 + 2	1 + 2	1 + 2
Number of refrigerant circuits	n°	1	2	2	2
Type of refrigerant		R410A			
Energy classification filters		ePM1 65% (F7)			
Power supply	V/ph/Hz	400/3/50			

⁽¹⁾ fresh air inlet +35 °C / 40% RH, return air +26 °C / 50% RH

⁽²⁾ fresh air inlet -10 °C / 90% RH, return air +20 °C / 50% RH

⁽³⁾ sound power level calculated in accordance with EN 3744

⁽⁴⁾ sound pressure level measured at 1 m free field distance, in accordance with EN 3744

8. VENTILATION CURVES


The graphs below indicate the operating limits of the EC fans installed on the units.

Consider the static pressure shown as available for ductwork, having a unit equipped with ePM₁₀ 60% (M5) filters on the return side and ePM₁ 55% (F7) on the supply side.




The operating limits of the units may vary depending on the configuration and the components installed. For different unit configurations, please refer to the selection software or contact the company.


SXH/HP 021




SXH/HP 031




SXH/HP 041




SXH/HP 061




SXH/HP 081




SXH/HP 101




SXH/HP 132




SXH/HP 172



SXH/HP 242



9. OPERATING LIMITS



All units can operate, within the given limits, with room relative humidity in the not exceeding 65%.



It is mandatory to use the units within the operating limits shown in the diagrams above. The warranty will immediately expire if the unit is used in working conditions outside the above limits. If it is necessary to operate in conditions outside the operating range of the unit, please contact our technical department.

10. SOUND DATA

The noise level of units is basically due to the fan rotation speed.

Obviously, with the same air flow rate, the fan speed will be lower if the required static pressure is low, while it will be higher (and therefore noisier) if the required static pressure is higher.

10.1 Noise levels

The table below shows the sound levels of the units at the nominal working conditions:

MOD.	Nominal air flow m ³ /h	E.S.P. Ret. Supp. Pa	Octave band (Hz)								Lw	Lw	Lp
			63	125	250	500	1K	2K	4K	8K	dB	dB(A)	dB(A)
021	2000	200 250	58	72	70	73	78	71	48	35	81	80	57
031	3000	200 250	58	72	70	73	78	71	48	35	81	80	57
041	4500	200 250	62	76	74	77	82	75	52	39	85	84	59
061	6000	200 250	62	76	74	77	82	75	52	39	85	84	59
081	8000	200 250	63	77	75	78	83	76	53	40	86	85	60
101	10000	200 250	63	77	75	78	83	76	53	40	86	85	60
132	13000	200 250	70	84	82	85	90	83	60	47	93	92	61
172	17000	200 250	72	86	84	87	92	85	62	49	95	94	63
242	24000	200 250	74	88	86	89	94	87	64	51	97	96	63

Lw: sound power level calculated in accordance with EN 3744

Lp: sound pressure level measured in free field at 1 m from the unit, directionality factor Q=2, according to EN 3744 with ducted unit.

10.2 Sound attenuators reduction

The sound attenuators are of sound-absorbing baffles type. They are suitable for reducing the noise that propagates through the ventilation systems in the aeraulic ducts.



To check the sound absorption data to the various octave band frequencies, please refer to the our selection software.

The sound attenuators are supplied in a dedicated section external to the base unit, thus increasing the total length of the unit (depth and height of the section remain the same as the base unit). Below are the additional section lengths according to size and profile, to be taken into account when calculating the final length of the unit.

Additional dimensions sound attenuator section (50 mm profile)

MODEL	021	031	041	061	081	101	132	172	242
Length [mm]	1000	1000	1000	1000	1000	1000	1000	1000	1000

Additional dimensions sound attenuator section (60 mm profile)

MODEL	021	031	041	061	081	101	132	172	242
Length [mm]	1020	1020	1020	1020	1020	1020	1020	1020	1020

11. SAFETY AND CONTROL DEVICES

- **Supply air temperature probe**

Passive sensor type NTC 10kΩ. Positioned on the supply air side, downstream of the heating/cooling units, it is used to monitor the temperature of the air supplied to the room. It is installed in combination with the temperature control accessories (water coils or post-heating electric resistance). Through this probe it is also possible to control eventual air delivery temperatures in the environment that are too cold in summer or too hot in winter.

- **Return air temperature probe**

Passive sensor type NTC 10kΩ. Positioned on the room air intake and upstream of the filtering section, its purpose is to monitor the temperature of the air extracted from the room to be treated. Always present in all units, it is used as a control probe of the room temperature set and for the management of the summer free-cooling function.

- **Outdoor air temperature probe (fresh air)**

Passive sensor type NTC 10kΩ. Positioned on the fresh air intake and upstream of the filtering section, it is used for monitoring the temperature of the fresh air entering the heat recovery unit. Always present in all units, it is used in combination with the room air intake temperature probe to manage the summer free-cooling function.

- **Exhaust air temperature probe**

Passive sensor type NTC 10kΩ. Positioned on the air outlet and downstream of the plate heat exchanger, it monitors the temperature of the air exhausted from the unit. It is installed in combination with the defrosting kit with the function of controlling the exhaust temperature of the plate heat exchanger in order to avoid freezing of the same during the winter operation of the unit.

- **Source exchanger defrost kit**

The source heat exchanger defrost kit is composed of a pressure transducer and a cycle inversion valve, directly managed by the microprocessor control. In case, in heating mode, the conditions downstream the plate heat exchanger should fall below the ice formation threshold, the defrost system would activate, which would invert the refrigerant gas flow and send hot gas to the heat exchanger to defrost.

As soon as the conditions downstream the heat exchanger would allow, the heating operating mode would be reset.

- **Differential pressure switch**

This component is used to monitor the clogging status of the air filters. There are two pressure switches for each unit, one installed on the fresh air filter section and one located on the room return air filter section. If one of the filters has a pressure difference greater than the recommended limit, an alarm is displayed on the user interface.

- **Differential pressure transducer**

Active type transducer with 4-20mA output signal. It is located inside the control board and connected to the supply fan pressure sockets. The task is to maintain the air volume as constant at the variation of the internal pressure drop (dirtying of the filters).

- **Low pressure switch**

The low pressure switch stops the unit when the suction gas pressure is lower than the default value. The reset is automatic and it takes place when the gas pressure is superior to the set differential value. The pressure switch is set to allow for a maximum of 3 automatic resets per hour.

- **High pressure switch**

The high pressure switch stops the unit when the supply gas pressure is above default value. The reset is automatic and it takes place when the gas pressure is below the set differential value. The pressure switch is set to allow for a maximum of 3 automatic resets per hour.

- **Compressor discharge temperature sensor**

Passive NTC-type sensor mounted on the compressor discharge side, used to limit the discharge gas temperature.

12. INSTALLATION

General warnings and use of symbols



Before carrying out any type of operation, each operator must be perfectly familiar with the operation of the machine and its controls and must have read and understood all the information contained in this manual.



All operations performed on the machine must be carried out by qualified personnel in compliance with the national legislation in force in the country of destination.



Installation and maintenance of the machine must be performed in compliance with applicable national or local legislation.



Do not approach or insert any object into moving parts.

Workers' Health and Safety



The operator's workstation must be kept clean, tidy, and free of objects that may restrict free movement. The workplace should be adequately lightened for the intended operations. Insufficient or excessive lighting may present a hazard.



Ensure that the ventilation of the working areas is always optimal and that the extraction systems are always functional, in good condition and in compliance with the legal requirements.

Personal protection devices



Operators carrying out installation and maintenance of the machine must wear the legally required individual protective equipment listed below.



Safety footwear.



Eye protection.



Protective gloves.



Hearing protection.



Respiratory protection.

12.1 Receipt and inspection

When installing or working on the unit, it is necessary to scrupulously follow the instructions given in this manual, observe the indications on board the unit and in any case apply all necessary precautions. Failure to follow these instructions may result in dangerous situations.

Upon receipt of the unit, check its integrity: the machine left the factory in perfect condition; any damage must be immediately reported to the carrier and noted on the Delivery Note before signing it.

The Company must be informed, within 8 days, about the extent of the damage. The Client must fill out a written report in case of significant damage.

Before accepting the delivery check:

- that the unit has not been damaged during transport;
- that the material delivered corresponds to what is indicated in the transport document.

In case of damages or anomalies:

- immediately note the damage on the Delivery Note;
- inform the supplier, within 8 days of receipt, of the extent of the damage. Reports made after this deadline are not valid;
- in the event of significant damage, file a written report.

12.2 Storage

If it is necessary to store the unit, leave it packed in a closed place. If for some reason the machine has already been unpacked, follow the instructions below to prevent damage, corrosion and/or deterioration:

- make sure all openings are properly plugged or sealed;
- do not use steam or other cleaning agents to clean the unit, as these may damage it;
- remove any keys used to access the control panel and give them to the site manager.

12.3 Unpacking



Packaging material (plastic film, expanded polystyrene, etc.) must be kept out of the reach of children as a potential hazard.

It is advisable to leave the units packed during handling and to remove the packaging only at the time of installation. Remove the packaging of the unit with care to avoid possible damage to the machine.

The materials making up the packaging can be of different kinds (wood, cardboard, nylon, etc.). It is advisable to remove the protective film from the panels (if present) after the installation of the unit.




Packaging materials should be stored separately and handed over for disposal or recycling to the appropriate.

12.4 Lifting and handling

Each unit section or single piece unit is provided with appropriate lifting points (lifting lugs or perimeter holes for lifting bars) clearly identified in the structural base.

When unloading the unit, it is strongly recommended that sudden movements are avoided in order to protect the internal component of the unit. Lifting procedure to be followed in order to avoid any damages to side panels is schematically shown on the pictures below, otherwise it is possible to proceed with the handling by means of forklifts.

It is important to keep the unit horizontal during the handling and lifting, avoiding absolutely to flip or tilt the sections.



Unit sections should be handled separately, before any assembly or coupling is made. After sections are assembled, it is NOT possible to move the whole resulting unit.



Weight of each section or unit module, as well as the unit total weight, are shown in the technical documentation supplied with the unit.

12.5 Positioning

12.5.1 Preliminary notice


The unit must be placed in a special area that can be made inside a technical room or outside in a covered area or not, depending on the structure on site.

Prior to proceeding to unit installation it is recommended to check the following:

- the structure (concrete or other) supporting the unit must be adequately designed for the unit static and operating weight; water mass forecasted in unit sumps must also be considered; supporting base should have an horizontal surface, flat and regular;
- The installation position must minimize the risks in the event of an earthquake or strong winds;
- Electric supply lines must be adequately sized according to the unit electric characteristics.

The positioning area for the unit can be obtained:

- directly on the floor (Fig. A)
- on a special concrete pedestal (Fig. B)
- on a pedestal in metal profiles (Fig. C)
- on a hanging structure in metal profiles (Fig. D)




In any case the following minimum requirements must be respected:



- The floor or pedestals must have suitable characteristics to support the mass of the unit in compliance with the required safety limits;
- The contact surface with the lower base frame of the unit must be sufficiently smooth and hard in relation to the mass of the machine;
- The floor or pedestals must allow the construction of siphons on the discharges with the provided hydraulic components;
- The horizontality of the support surface must be checked and any corrections can be obtained using metal shims.

Special precautions must be taken in case of unit supplied splitted into sections and / or large dimensions where it's not envisaged the creation of a positioning place with a single and continuous surface:


- as well as at the begin and end of the unit, points of support must be made in correspondence with any intermediate junctions between individual sections (detectable by the drawing of the machine and / or checked with our Technical Department) (Fig. E (concrete)- Fig. E1 (IPE beams));



- in case of overhead positioning, the individual support points must be realized in order to support the corresponding mass of the section in consideration of the unit's height and in compliance with the safety limits for seismic risk. (Fig. F (concrete) Fig. F1 (structure in metal profiles));



- the surface of the support points must have a suitable width to allow positioning/approaching and assembly operations of the individual sections during the installation phase (Fig. G);
- the contact surface with the base frame must be sufficiently hard and smooth to allow positioning/approaching and assembly operations in relation to the mass of the unit;
- the overall planarity of all the individual support points must be checked and if necessary corrected using metal shims.


READ AND UNDERSTAND THE INSTRUCTIONS

Before undertaking any task the operator must be fully trained in the operation of the machines to be used and their controls. They must also have read and be fully conversant with all operating instructions.




All maintenance must be performed by TRAINED personnel and be in accordance with all national and local regulations.



The installation and maintenance of the unit must comply with the local regulations in force at the time of the installation.

12.5.2 Service area requirements

Area chosen for unit assembly must allow sufficient clearance space, around and on top of unit, for unit installation and further ordinary and extraordinary maintenance operations. Particularly important is the service area on the inspection and connection side, in order to allow panels to open completely and coils to slide out completely for extraordinary maintenance. The picture below show minimum clearances requested.



The unit has to be installed such that maintenance and repair is possible. The warranty does not cover costs for the provision of lifting apparatus, platforms or other lifting systems required to perform repairs during warranty period.



The units are supplied as standard in a MONOBLOCK configuration, in case of multi-section units, they are available in special execution. Please contact the Company for further details.

12.6 Section coupling and bolting


For unit delivered in separate sections, it is necessary to proceed to the total assembly on site, according to the overall drawings provided with the unit.

1. Apply supplied self adhesive gasket along the perimetrical face of one of the sections to be coupled.
2. Position first the heaviest section, then set beside the second one and embed it in the provided corner mortises.
3. Bolt sections together by means of holes provided in the profiles and using M8 bolts supplied with the unit. Fasten gradually and alternatively along the full perimeter (fastening couple 8-12 Nm/0,8-1,2 kgm) until gasket between profiles is fully and uniformly presse.


Assembly of union bolts is carried out through inspection panels, or by disassembling side panels adjacent to union profiles; as side panels are secured on to profiles by self-threading screws, highest care is required for re-assemblyng the same, in order not to break panel seal gasket and not to dent panel surfaces. In some cases it may be necessary to partially remove the coils and/or droplet eliminator to access to the junction plates.

4. Apply the sealing cord, supplied with unit, on the two sides and on top of the union perimeter.

EXTERNAL JUNCTIONS SCHEME



INTERNAL JUNCTIONS SCHEME



Install the unit to allow ordinary and extraordinary maintenance. The warranty does not cover costs related to platforms or handling equipment necessary for any intervention.




Choose the installation site in accordance with EN 378-1 and 378-3.

12.7 Hydronic connections

All connections should be made with the best available current workmanship practice according to the indicated dimensions of inlet and outlet diameters.

Outlet connections should be complete with water traps and their height calculated on the basis of the maximum negative pressure existing at the drainage point. A simplified method is to assume this value equal to the total fan pressure and calculate trap dimension as indicated in the picture below.



$$S1 = Ht / 10 + 35$$

$$S2 = Ht / 10 \times 0,75$$

S1- S2 = minimum height, mm, as indicated

Ht = total fan pressure, Pa, as indicated in the "TECHNICAL SCHEDULE"



Each drain must be independent and have its own siphon.
The lack of a siphon may affect the proper operation of the unit.



It is advisable to provide a siphon for EVERY SINGLE DRAIN. We also recommend that separated drains are NOT connected with each other, before or after the siphon/s, but are left independent.

12.8 Hydraulic connection to the exchange water coils

The following requirements for water connections are also applicable for coils with other fluid, such as glycol solutions, diathermal oil, etc. The following minimal requirements are recommended for any type of installations.

- Provide appropriate supports for external circuit and thermal expansion joints with vibration isolators; avoid to load coil connections.
- Position water pipes and water circuit devices not to impede coil slide out, inspection panel openings and access to any unit sections.
- Avoid damages to coil connection solderings by fastening mechanical connections with care without applying any torsions to the same especially when the exchangers are small.




Coil performance is normally rated for counter-flow circuit arrangement, consequently coils are provided with water inlet at the bottom and downstream air flow, outlet at the top and upstream air flow. The stickers on the unit with the respective inlet and outlet symbols placed near the headers respect this rule.

Furthermore, water circuit should be provided with:

- water drain to be positioned at the unit lowest point (obligatory);
- vent valve at the circuit highest point to allow easy replenishment (recommended);
- shut-off valves, on water inlet and outlet, to allow coil disassembly for extraordinary maintenance;
- for hot water coils, water pump electric interlock with the fan cycling device or circuit bypass, to avoid damages resulting from overheated stagnating air, during fan shutdown periods.

Installer must obviously guarantee the requested value of water flow.

12.9 Connecting the unit to air ducts



Fixing of air ducts

GENERAL RULES

For a correct installation of the ductwork it is recommended to:

- design the duct so that the air speed never exceeds 4-5 m/s, for the purpose of noise containment;
- provide suitable brackets to support the ducting to prevent their weight from bearing on the unit;
- always use a flexible joint between the unit and the ductwork;
- provide an electrical earth cable to bridge the flexible joint, to ensure the duct and the unit are electrically equipotential;
- before bends and branches, provide a straight duct with a length equal to at least 2.5 times the diameter of the duct to avoid drops in fan performance.

13. MODBUS-RS485 / BACnet serial interface card

Serial line interface card to the supervision system (available only MODBUS-RS485 / BACnet). The installation of the card will allow the unit to be connected to a system with MODBUS-RS485 / BACnet protocol.


This system allows you to remotely monitor all the operating parameters of the unit and change their values. The serial interface card is installed and wired exclusively in the factory.

The unit does not work in case of inversion of the polarity of the wiring.


The list of MODBUS / BACnet variables is available by contacting the company.

14. FILTERS and HEAT EXCHANGER extraction

In order to service / replace the air filters, they must be accessed by opening the inspection doors located on the front of the unit (inspection side), as shown in the picture here below.




In order to inspect, service and extract the heat exchanger, unscrew the screws on the rear panel of the unit (opposite the inspection side), as shown in the picture here below.



Do not use water to clean the heat exchanger. It is however possible to vacuum the rear part of the heat exchanger after removing it, as shown on the picture.

15. REFRIGERANT DIAGRAM


15.1 Refrigerant circuit with 1 compressor



COMPONENTS OVERVIEW

CM	Compressor type Scroll	SGL	Liquid / humidity indicator
NR1	Non-return valve on supply	TEE	Electronic expansion valve
ECH	Heater on compressor crankcase	DFL	Liquid line filter drier
INV_C	Frequency converter on compressor	LVC	Liquid line tap
LPT	Transducer LP	LR	Liquid receiver
HPS	Pressure switch HP with manual reset	RES	Air/air plate heat recovery exchanger
HPD	Safety valve HP	OUA	Fresh air inlet
HPT1 - HPT2	Transducer HP	RET	Return air inlet
STA	NTC probe on suction	FA1	Air filters
RFW	4-way reverse valve	D.1M	Supply line CU (DN max 32)
REC	Finned recovery exchanger	D.2A	Suction line CU (DN max 32)
ECE	Extraction fans	D.3A	Common suction/supply CU (DN max 32)
ICR	Finned internal exchanger	D.L1	Liquid line CU (DN max 32)
ECS	Supply fans	D.L2	Liquid expansion line CU (DN max 32)
NR2	Liquid line non-return valve	PSV	Single service outlet with pressure pin
NR3	Expansion line non-return valve	PSV1	Double service outlet with pressure pin
		D.6	Capillary tube CU (optional)

15.2 Refrigerant circuit with 2 compressors



COMPONENTS OVERVIEW

CM	Compressor circuit 1	SGL	Liquid / humidity indicator
DSV	Globe type tap on supply	TE2	Electronic expansion valve
ECH	Heater on compressor crankcase	DFL	Liquid line filter drier
SCV	Globe type tap on suction	LVC	Liquid line tap
LPS	Low pressure switch	LR	Liquid receiver
HPS	Pressure switch HP with manual reset	RES	Air/air plate heat recovery exchanger
HPD	Safety valve HP	OUA	Fresh air inlet
HPT	Transducer HP	RET	Return air inlet
TE1	Mechanical summer thermostatics	FA1	Air filters
RFW	4-way reverse valve	D.1M	Supply line CU (DN max 32)
REC	Finned recovery exchanger	D.2A	Suction line CU (DN max 32)
ECE	Extraction fans	D.3A	Common suction/supply CU (DN max 32)
ICR	Finned internal exchanger	D.L1	Liquid line CU (DN max 32)
ECS	Supply fans	PSV	Single service outlet with pressure pin
NR1	Liquid line non-return valve	PSV1	Double service outlet with pressure pin
NR3	Expansion line non-return valve	D.6	Capillary tube CU (optional)

16. ELECTRICAL CONNECTIONS

Preliminary safety information



The electrical connection must be made according to the wiring diagram enclosed with the unit and in compliance with local and international regulations.



Make sure the disconnector of the unit power supply line is upstream the unit. Ensure it is padlocked or that the appropriate warning is present indicating not to operate.



Check that the power supply corresponds to the rated data of the unit (voltage, phases, frequency) shown on the wiring diagram and on the nameplate attached to the unit.



Power supply cables must be protected upstream against electric short-circuit and overload by a suitable device complying with current standards and laws.



The cross-section of the cables must be suitable for the calibration of the upstream protection system and must take into account all factors that may affect it (temperature, type of insulation, length, etc.)



The warranty will be void if the power supply does not comply with the above limits.



Make all earthing connections required by current standards and legislation.



Make sure to disconnect the power supply before beginning any operation.



FROST PROTECTION:

when open, the main switch excludes the electric power to the heating elements and any antifreeze device in the unit. Open the main switch only for cleaning, maintenance or repair of the unit.

16.1 Electrical data



The following electrical data refer to the basic unit without accessories.
In all other cases, refer to the electrical data in the wiring diagram attached to the unit.



The supply voltage must not vary more than $\pm 10\%$ of the nominal value and the unbalance between phases must be less than 1% according to EN 60204.
Please contact our technical department in case these tolerances are not respected.


MODEL	021	031	041	061	081	101	132	172	242
Power supply	V/Ph/Hz 400/3/50 V/Ph/Hz								
Control circuit	12 VDC / 24 VAC								



Electrical data may change without notice. Therefore, ALWAYS refer to the wiring diagram supplied with the unit.

16.2 Power supply connection

The electrical panel is located inside the unit and it is accessible through the inspection door on the front of the unit (inspection side). To connect the power supply, use the cable gland on the side panel of the section and connect the power cable inside the electrical cabinet to the disconnecting main switch.




16.3 Terminal Block Connections




Terminal numbers may change without notice. ALWAYS refer to the wiring diagram supplied with the unit.

All the terminals shown in the following tables are in the terminal block inside the electrical cabinet, all the electrical connections mentioned below must be made in the field by the installer.




THREE-PHASE POWER SUPPLY

It is used to power supply all the units with three-phase system.
The power cable should be connected directly to the mains switch.
The earth terminal is present (PE).




REMOTE ON/OFF

It is used to turn on/off the unit from a remote device.
The units are supplied as standard from the factory with jumpered terminals.
Closed contact: unit is **ON**;
Open contact: unit is **OFF**.



FIRE/SMOKE ALARM

It is used to turn off the unit from an external fire control unit.
The units are supplied as standard from the factory with jumpered terminals.
Closed contact: no unit alarm works;
Open contact: alarm from external fire control unit. The unit stops.



REMOTE GENERAL ALARM

For remote signalling of a general alarm.
Voltage-free contact.

16.4 Connections on main board



FieldBus2
/BMS

MODBUS RS-485 CONNECTION on port BMS / FieldBUS2

Rx- / Tx- connect the negative pole (-) of the ModBus network;

Rx+ / Tx+ connect the positive pole (+) of the ModBus network;

GND connect the GND of the ModBus network;

allows connection to a supervisory system (BMS) via ModBus RTU communication protocol on RS-485 serial line.




Display
port

ADDITIONAL DISPLAY CONNECTION

Display port allow connection of an additional display on a serial dedicated port.

16.5 Description of the remotable control panel


16.5.1 Position of the control panel



16.5.2 Remote panel keys

KEY	FUNCTION
	Pressing this key you will access the list of alarms presently active and you silence the siren. Inside the alarms list, if pressed for at least 3 seconds, the manual-reset alarms will be reset.
Prg	Pressing this key you will access a LOGIN screen which will allow you to access the main parameters modification menu. According to the password you insert, SERVICE or MANUFACTURER , it will be possible to modify the parameters or just view them.
Esc	Pressing this key you will exit the present screen and return to the previous menu.
	Scroll the masks of a specific menu or, in case of a parameter, modification of its value.
	Confirm the value of a chosen parameter or selection of an item in case of a menu.
	Scroll the masks of a specific menu or, in case of a parameter, modification of its value.


16.5.3 Dimensions



16.5.4 Wall installation


The wall mounting of the control panel considers the fixing of the back side of the container A or the standard 3-module case for switches.

- Fix the container to the box using the thumbscrews supplied with it in the packing;
- Connect the telephone wire;
- Apply the container front side and fix the set with countersunk screws (as shown in the picture) supplied with the casing;
- At the end, install the snap-in frame.



16.5.5 Electrical connection

Connect the telephone wire coming from the card in the dedicated connector located on the back side of the terminal unit.



For the electrical connections to the remote control panel, please refer to the wiring diagram supplied with the unit.



In case of damage of the controller/remote terminal, wiring error, lack of communication between the tool and the remote panel, a message on the display will appear indicating "noL" (no link).

17. STARTUP

17.1 Preliminary checks

It is necessary to carry out preliminary checks on the electrical, refrigeration and hydraulic parts before starting the unit.



Perform the commissioning operations in accordance with all the requirements of the previous paragraphs.



Malfunctions or damage may also result from lack of proper care during shipment and installation. It is good practice to check before installation or commissioning that there are no damages due to tampering, vibration during transport, mistreatment suffered on site.

- Check that the machine is installed in a state of the art manner and in accordance with the instructions in this manual.
- Check electrical connection and correct fastening of all terminals.
- Check that the voltage is as indicated on the unit's rating plate.
- Check that the unit is connected to the earth system.
- Check that no gas leakages are present, if necessary with a gas-leak detector.
- Check that no oil leaks are present, which might be indicating leakages.
- Check that the refrigerant circuit is in pressure: use manometers, if available, or service manometers.
- Check that all service outlets are closed with the appropriate caps.
- Check that the hydraulic connections have been installed correctly and that all indications on the nameplate are respected.
- Check that the system has been properly vented.
- Check that fluid temperatures are within operating limits.
- Before turning the unit on, check that all closing panels are in place and secured with the appropriate screws.



Do not modify the internal electrical connections as this will immediately invalidate the warranty.



If present, the electric heaters for the compressors must be turned on at least 12 hours before the start-up (pre-heating phase), shutting down the main switch (the heaters are fed automatically when the switch is OFF). The heaters operate correctly if, after a few minutes, the crankcase temperature of the compressor is 10÷15°C higher than the air temperature.



In case of presence of electric heaters for the compressors, during the 12 hours of pre-heating phase, it is important to check on the display whether the OFF indication is present or that the unit is in stand-by mode. In case of accidental start, before this 12-hour pre-heating time has elapsed, the compressors might seriously be damaged and the warranty would decay immediately.

17.2 Checks during the operation


Check the rotation of the compressors and the fans. If the rotation is incorrect, immediately disconnect the unit from the main switch and change any one of the phases entering the main switch, so as to invert the rotation sense of the motors.


After a few operating hours, check the liquid sight glass has a greenish colour on its central part: should this be yellow, then some humidity could be present inside the circuit. In this case it will be necessary to dehydrate the circuit (only to be done by qualified personnel). Check that no air bubbles appear on the liquid sight glass. In this case it would be necessary to reintegrate the refrigerant charge. The presence of steam bubbles is however tolerated.

Some minutes after the switching on of the unit, check that the equivalent temperature of the refrigerant gas, as measured at the pressure present inside the coil with fans operating at the maximum velocity, differs from the fresh air temperature by some 7-10°C; also check that the equivalent temperature of the refrigerant gas, as measured at the pressure present inside the plate heat exchanger, differs from the water temperature going out of the exchanger by some 3-5°C.

18. UNIT USE

18.1 Function of display icons



ICON	FUNCTION
	This icon allows you to access the screen for turning on the unit.
Set	Allows access to the page for changing set points and switching on the Drycooler.
i	Allows access to the menu with general information on the unit.

18.2 Factory default settings

The variable set points that can be changed by the user are:

SYMBOL	FUNCTION	ADMISSIBLE LIMITS	FACTORY VALUES
SEt U	Summer humidity setpoint	40 ÷ 80 %	60 %
SEt C	Summer temperature setpoint	18 ÷ 30 °C	26 °C
SEt H	Winter temperature setpoint	18 ÷ 25 °C	22 °C
PAS	Password	(Please contact our service office)	



All setpoints refer to the room air air conditions.



The units are equipped with a highly-sophisticated control system, with several parameters which may not be modified by the end user; these parameters are protected by manufacturer password.

18.3 Switching on and parameters setting

SWITCH THE UNIT ON


Once the heat recovery unit is supplied electrically and the main switch turned on, the display will be activated and will show the "OFF" screen, meaning unit OFF from keyboard.

From this screen, press the key  or  to switch the unit on.





MAIN SCREEN

At the start of the unit, the following screen will appear, showing the main operating and functioning parameters.



USER MENU

The visualization of the menu is done by pressing the key  or .

The following menus will be shown cyclically:



INFO




SET

ALARM

SET MENU



VISUALIZATION OF SET POINTS

The display of the set points is done by pressing the key  or .



SET POINTS SETTING AND OPERATING MODE

To define the setpoints you need to be in the menu SET ; **Set**

Press key  or  to select the setpoint you wish to modify;

Confirm with key  ;

Press key  or  to modify the parameter;

Confirm with key  ;

Likewise also the operating mode, summer/winter, may be set.

INFO MENU

To display the info menu and all the operating parameters you need to access the INFO menu.



Press the key  or  to display the following parameters:

```
Info - Plant
Ret.temp.: 19.0°C
Setpoint: 24.0°C
Request: 0.0[%]

Main:  0.0
```

Information on the thermal controls of the unit.

```
Info - Damper
|/| Status: CLOSE
|/|
|/|
|/|
```

External air damper position ON/OFF.

```
Info - Supply Fan
Req.: 0.0[m3/h]
Setp.: 15000.0[m3/h]
Ret.: 0.0[m3/h]
[⇒]
Request: 0.0%
Speed: 0rpm
```

Information on the control of the supply fan.

```
Info - Return Fan
Probe: 0.0[m3/h]
[⇒]
Request: 0.0%
Speed: 0rpm
```

Reading of the retrun air differential pressure sensor and return air fan request.

```
Info - Recovery
T.Rec.: 19.0°C
[◇] Status: OFF
Defrost Req.: [%]
 0.0
(Bypass damper)
```

Information on the by-pass damper of the heat recovery unit.

```
Info - Circuit 1
Req: 0% → Run: 0%
-44.8BAR → -400.0°C P
19.1°C T
STATUS:
25.5°C T
0.0BAR → -51.4°C P
```

Information on the compressor control and status.

```
Info - Humidity
Ambient Hum.: 44.5%
OK SP.Hum.: 40.0%
SP.Dehum.: 50.0%
Request: 0.0[%]
Dehu.:  0.0
Help:  0.0
```

Information on the humidity control.

```

Info - Post-Heating
SUPP.T.: 19.2%
Setp.: 10.0%

Request: [%]
0.0
  
```

Information on the post-heating control.

```

Info
VORTICE

Code: VORSTDUTA
Date: 28/01/2021
SW ver.: 1.0.000
OS ver.: 4.7.001
BOOT ver.: 4.7.001
  
```

Software version, boot and OS.

```

Info

Board type:
Board size: Large
Core: 0

UID: 0001000000000EF7
  
```

Hardware information.

```

Info

Ret mem writes: 18328
Main task:
139ms 7.2Cycle/s
  
```


Performance hardware.

```

Info
Blackout info
Current time:
01/02/00 02:05:11
PowerOff time:
01/01/## 01:00:00
Length last time off:
###Days 0Hrs 0Min
  
```

Blackout info.

Pressing the key **Esc** in correspondence with the different displays, you will access the under-menus of the various components, as instance:



18.4 Enabling time bands

Press the button **Prg** to access the main menu for changing parameters. If required, enter the password **0000** to access. Go to the **Scheduler** menu item and then activate the time bands with the option **Enable? Yes**.

```
SCHEDULER
Enable?      Yes
15:38 THU 11/08/2022
Sched. is not running
Unit status: AUTO
```

1° Enabling time bands management.

Time bands management is divided into the following order of priority:

- Special days;
- Vacation periods;
- Days of the week.

The operating modes of the unit in settable time bands are as follows:

- Unit off (**OFF**);
- Economy mode (**ECO**);
- Pre-comfort mode (**P-C**);
- Comfort mode (**COM**).

In the economy, pre-comfort and comfort modes, the following setpoints can be defined:

- Cooling;
- Heating.



The settable setpoints are accessible according to the configured unit type.

```

DAILY EVENTS
Day: Monday
Copy to: MON Ok? No
[✓] 1 00:00 OFF
[✓] 2 02:01 ECONOMY
[✓] 3 04:11 PRE-COMFORT
[✓] 4 12:56 COMFORT
Save data? No

```

- 1° Selection day on which the time bands are to be configured.
- 2° Select day to which the currently selected time bands are to be copied.
- 3° Confirm copy time bands.
- 4°-7° First/Second/Third/Fourth configurable time bands.
(Up to 4 time bands can be configured per day).
- 8° Confirm saving of configured time bands.

```

VACATIONS PERIODS
Start End Status
[✓] 01/01 05/02 PRE-COMF
[✓] 08/06 08/07 OFF
[✓] 20/12 24/12 ECONOMY

```

- 1°-3° First/Second/Third configurable vacation period.
(Up to 3 vacation periods can be configured)

```

SPECIAL DAYS
[✓] 1 25/12 COMFORT
[ ] 2 --/-- --
[ ] 3 --/-- --
[ ] 4 --/-- --
[ ] 5 --/-- --
[ ] 6 --/-- --

```

- 1°-6° First/Second/Third/Fourth/Fifth/Sixth configurable special days.
(Up to 6 special days can be configured)

```

SCHEDULER
Cooling Setpoint
Economy: 25.0%
Pre-comfort: 23.5%
Comfort: 23.0%

```

- 1° Cooling setpoint in economy mode (ECO).
- 2° Cooling setpoint in pre-comfort mode (P-C).
- 3° Cooling setpoint in comfort mode (COM).
- When the unit is in scheduler off (OFF), the working setpoint of the automatic mode (AUTO) is maintained.

```

SCHEDULER
Heating Setpoint
Economy: 19.0%
Pre-comfort: 20.5%
Comfort: 21.0%

```

- 1° Heating setpoint in economy mode (ECO).
- 2° Heating setpoint in pre-comfort mode (P-C).
- 3° Heating ling setpoint in comfort mode (COM).
- When the unit is in scheduler off (OFF), the working setpoint of the automatic mode (AUTO) is maintained.

19. CONTROLS

19.1 Fans

Two types of controls can be set for the fans:

- Regulation with the pressure differential;
- Regulation with flow rate.


It is possible to enable CO₂ control, which modifies the control setpoint of the fans according to the value of CO₂.

It is possible to set a minimum and a maximum speed for the fans.

In the case of return fans, it is possible to change the speed of the return fans in relation to the supply fans via a parameter.

When the unit is switched on, the supply fans have a switch-on delay with respect to the damper opening, then a delay time can be set between the switching on of the supply and return fans.

The damper closes with an adjustable delay time relative to the supply fans.




These machines are units that include the possibility of meeting pool demand by readjusting their controller and using specific inputs and outputs. The inputs and outputs are located on the c.pCOe board (address 15) and are:

- Hot or cold pump thermal digital input;
- Unoccupied / occupied status digital input;
- Pool water recovery inlet temperature analogue input;
- Recirculation damper analogue output;
- Alpha cycle damper digital output;
- Pool valve digital output (VHG heat recovery water preheating).

Zones are defined for room temperature and room humidity relative to their setpoints. Depending on the temperature and humidity zone the Alpha cycle damper and the recirculation damper are opened, closed or modulated.

Depending on the temperature and humidity zone, pool demand management is enabled.

Below is an example of the definition of the temperature and humidity zones, the temperature zones vary in position depending on the control mode.



19.2 Adjusting dampers

19.2.1 Alpha cycle damper

The Alpha cycle damper is opened when:

- The room temperature is in zone 4;
- The room humidity is in zone 1 or zone 2.

When the Alpha cycle damper is open the main compressor control is determined by the demand for dehumidification.

NB: Outside the condition where the Alpha cycle damper is open, the PID of the dehumidification demand is always disabled, as dehumidification is delegated to the management of the recirculation damper.


19.2.2 Recirculation Damper

The various conditions and consequent modulation of the recirculation damper are shown below:

- Recirculation damper at minimum opening:
Room temperature is not in zone 4;
Room humidity is in zone 2.
- Modulating recirculation damper
Room temperature is not in zone 4;
Room humidity is in zone 1.

Under these conditions the recirculation damper modulates within the room humidity zone 1, from its maximum opening to its minimum opening.

- The recirculation damper is forced to maximum opening when one of these conditions occurs:
 The room temperature is in zone 4;
 The room temperature is not in zone 4 and the room humidity is in zone 0, zone 3 or zone 4;
 The refrigeration circuit is doing the defrosting procedure.




19.3 Pool request controls

Pool demand management is enabled when the following conditions occur:

- The room temperature is in zone 0, zone 3 or zone 4;
- The Alpha cycle damper is closed;
- The number of active compressors is less than or equal to 1 and the inverter compressor speed is at idle (this condition does not reset pool demand management when it has already been enabled);
- Pool demand is greater than 2%;
- The temperature PID is active;
- Cooling circuit 1 is not in serious alarm;
- Pool recovery temperature is not in alarm;
- The compressor thermal with inverter of circuit 1 is not active.

When pool demand management is enabled, the unit performs the following operations:

- Pool valve activation;
- Forced disablement of cooling circuit 2;
- Main request controlled by pool demand.



SERVICE OR MANUFACTURER MENU

Pressing the key **Prg** you will access the main parameters modification menu.

Depending on the **SERVICE** or **MANUFACTURER** password, it will be possible to modify these parameters or only view them.

20. DIAGNOSIS AND TROUBLESHOOTING

20.1 Troubleshooting

All units are checked and tested at the factory before delivery, however, it is possible that some anomaly or failure may occur during operation.



It is recommended to reset an identification alarm only after removing the cause that generated it; repeated resets may result in irreversible damage to the unit.


CODE	ALARM DESCRIPTION	PARAMETERS
AL001	Too many mem writings	
AL002	Retain mem write error	
AL003	Return temperature probe error	
AL004	Supply temperature probe error	
AL005	External humidity probe error	
AL006	External temperature probe error	
AL007	Recovery temperature probe error	
AL008	Ambient humidity probe error	
AL009	CO2 probe error	
AL010	Supply differential pressure probe error	
AL011	Return differential pressure probe error	
AL012	Discharge pressure circ.1 probe error	
AL013	Suction pressure circ.1 probe error	
AL014	Discharge temperature circ.1 probe error	
AL015	Suction temperature circ.1 probe error	
AL016	Liquid temperature circ.1 probe error	
AL017	Discharge pressure circ.2 probe error	
AL018	Suction pressure circ.2 probe error	
AL019	Discharge temperature circ.2 probe error	
AL020	Suction temperature circ.2 probe error	

CODE	ALARM DESCRIPTION	PARAMETERS
AL021	Liquid temperature circ.2 probe error	
AL028	Alarm remote	
AL029	Alarm antifreeze switch	
AL030	Overload heater	
AL031	Alarm air filter	
AL032	High compression ratio circuit 1	
AL033	High discharge pressure circuit 1	
AL034	High motor current circuit 1	
AL035	High suction pressure circuit 1	
AL036	Low compression ratio circuit 1	
AL037	Low differential pressure circuit 1	
AL038	Low discharge pressure circuit 1	
AL039	Low suction pressure circuit 1	
AL040	High discharge temp. circuit 1	
AL041	High compression ratio circuit 2	
AL042	High discharge pressure circuit 2	
AL043	High motor current circuit 2	
AL044	High suction pressure circuit 2	
AL045	Low compression ratio circuit 2	
AL046	Low differential pressure circuit 2	
AL047	Low discharge pressure circuit 2	
AL048	Low suction pressure circuit 2	
AL049	High discharge temp. circuit 2	
AL050	Low SuperHeat EVD circuit 1	
AL051	LOP EVD circuit 1	
AL052	MOP EVD circuit 1	
AL053	High condensing temp. EVD circuit 1	
AL054	Low suction temp. EVD circuit 1	
AL080	Alarm HP circuit 1 pressure switch	
AL081	Alarm LP circuit 1 pressure switch	
AL082	Overload compressor 1 circuit 1	
AL083	Overload compressor 2 circuit 1	
AL084	Overload compressor 3 circuit 1	

CODE	ALARM DESCRIPTION	PARAMETERS
AL086	Alarm HP circuit 2 pressure switch	
AL087	Alarm LP circuit 2 pressure switch	
AL088	Overload compressor 1 circuit 2	
AL089	Overload compressor 2 circuit 2	
AL090	Overload compressor 3 circuit 2	
AL092	Warning timeout recovery defrost	
AL155	Offline supply diff.pressure sensor	
AL156	Offline return diff.pressure sensor	
AL274	Offline cpCOe 1	
AL275	Configuration error cpCOe 1	
AL276	Serious alarm supply fans 0-10V	
AL277	Serious alarm return fans 0-10V	
AL278	Overload coil 1 pump	
AL279	Overload coil 2 pump	
AL280	Overload heating coil pump	
AL281	Inlet rec.pool temp. probe error	

21. DIMENSIONAL DRAWINGS

CONFIGURATION H1



Due to the large number of configurations available, only general dimensional drawings are shown, which are to be considered purely indicative and may change without notice. The specific drawing of the ordered unit is present in the documents supplied with the unit itself.

GENERAL DIMENSIONAL DATA (50 mm profile)

MOD.	021	031	041	061	081	101	132	172	242
A [mm]	2900	3250	3650	3650	3900	4000	4360	4900	5300
B [mm]	1350	1500	1650	1900	2150	2250	2280	2380	2380
C [mm]	1270	1300	1550	1700	1700	1820	2220	2550	2750
Weight [kg]	464	581	714	929	1043	1160	1375	1706	1932


Dimensions and weights refer to standard version without accessories

GENERAL DIMENSIONAL DATA (60 mm profile)

MOD.	021	031	041	061	081	101	132	172	242
A [mm]	2920	3270	3670	3670	3920	4020	4380	4920	5320
B [mm]	1370	1520	1670	1920	2170	2270	2300	2400	2400
C [mm]	1290	1320	1570	1720	1720	1840	2240	2570	2770
Weight [kg]	473	592	728	947	1064	1183	1402	1740	1970

Dimensions and weights refer to standard version without accessories

CONFIGURATION H2



Due to the large number of configurations available, only general dimensional drawings are shown, which are to be considered purely indicative and may change without notice. The specific drawing of the ordered unit is present in the documents supplied with the unit itself.

GENERAL DIMENSIONAL DATA (50 mm profile)

MOD.	021	031	041	061	081	101	132	172	242
A [mm]	2900	3250	3650	3650	3900	4000	4360	4900	5300
B [mm]	1350	1500	1650	1900	2150	2250	2280	2380	2380
C [mm]	1270	1300	1550	1700	1700	1820	2220	2550	2750
Weight [kg]	464	581	714	929	1043	1160	1375	1706	1932

Dimensions and weights refer to standard version without accessories

GENERAL DIMENSIONAL DATA (60 mm profile)

MOD.	021	031	041	061	081	101	132	172	242
A [mm]	2920	3270	3670	3670	3920	4020	4380	4920	5320
B [mm]	1370	1520	1670	1920	2170	2270	2300	2400	2400
C [mm]	1290	1320	1570	1720	1720	1840	2240	2570	2770
Weight [kg]	473	592	728	947	1064	1183	1402	1740	1970

Dimensions and weights refer to standard version without accessories

22. UNIT MAINTENANCE

22.1 General warnings



As of 01 January 2016, the new European Regulation 517_2014, "Obligations arising in relation to the containment, use, recovery and distribution of fluorinated greenhouse gases used in stationary refrigeration, air conditioning and heat pump equipment" has become applicable. The unit in question is subject to the regulatory obligations listed below, which must be fulfilled by all operators:

- a) Keeping of equipment records;
- b) Correct installation, maintenance and repair of the equipment;
- c) Leakage control;
- d) Recovery of refrigerant and eventual management of disposal;
- e) Submission to the Ministry of Environment of the annual declaration concerning emissions into the atmosphere of fluorinated of fluorinated greenhouse gases.

Maintenance allows you to:

- Keep the unit efficient.
- Prevent possible breakdowns.
- Reduce the rate of deterioration of the unit.



It is advisable to provide a unit booklet with the purpose of keeping track of the interventions carried out on the unit, facilitating the potential search for faults.



The maintenance operations must be carried out in compliance with all the prescriptions of the previous paragraphs.



Use personal protective equipment as required by current regulations.

22.2 Access to the unit

Access to the unit once it has been installed must be allowed only to authorised operators and technicians.

The owner of the machine is the legal representative of the company, body or natural person who owns the plant where the machine is installed.

He is responsible for observing all the safety rules indicated in this manual and in the regulations in force.

22.3 Periodical checks



Commissioning operations must be carried out in accordance with all the requirements of the previous paragraphs.



All operations performed on the unit must be carried out by qualified personnel in compliance with the national legislation in force in the country of destination.

Every 6 months

It is good practice to carry out periodic checks to ensure that the unit, control and safety devices are functioning correctly.

- Check that the electric terminals inside the compressor terminal plates are correctly fixed.
- Periodically clean the mobile and fixed contacts of the contactors.
- Check that there are no water leakages in the hydraulic circuit.
- Check that the flow switch operates properly, clean the metallic filter installed in the water pipe.
- Check that the crankcase heaters are supplied and operate properly (on a monthly basis).
- Check the condition of the finned coils, if necessary clean with compressed air in the opposite direction to the air flow. If the coil is completely clogged, clean it with a low-pressure cleaner, taking care not to damage the aluminium fins.
- Check the attachment and balance of the fans.

Unit shutdown

In case of long period shutdown, the hydraulic circuit must be drained so that there is no more water in the pipes and the exchanger.

This operation is compulsory if, during the shutdown period, the ambient temperature can fall below the freezingpoint of the mixture used (typical seasonal operation).

22.4 Refrigeration circuit repair



Please remember that, in case it is necessary to discharge the refrigerant circuit, it will be mandatory to recuperate all of the refrigerant gas by suitable machinery.

The system must be charged with nitrogen using a tank equipped with reducer, up to a pressure of approx. 15 bar. Leakages, if any, must be detected with a leakage detector. The formation of bubbles or foam indicates the presence of localised leakages. In this case, it will be necessary to discharge the circuit before carrying out the weldings with suitable alloys.



Never use oxygen instead of nitrogen: elevate explosion risk.

Refrigerant circuits operating with refrigerant gas require specific care in mounting and maintenance operations, in order to prevent them from operation anomalies.

It is therefore necessary to:

- Avoid refills with oil different from the specific one already charged in the compressor.
- For units using refrigerant gas R134a or R410A, in case there are leakages such as to make the circuit also partially discharged, avoid refilling the missing refrigerant gas, but discharge the unit completely, recuperating the refrigerant gas for successive disposal. After vacuuming the circuit, recharge it with the suitable quantity.
- In case of replacement of any part of the refrigerant circuit, do not leave the circuit open for more than 15 minutes.
- In particular, in case of compressor replacement, complete the operation within the time indicated above, after removing the rubber caps.
- In case rubber caps of compressor replacement, we recommend to wash the refrigerant circuit with suitable products. We also recommend to insert, for a determined time, an anti-acid filter.
- In vacuum conditions, do not supply the compressor electrically; do not compress air inside the compressor.

23. DISMANTLEMENT, MATERIALS' DISPOSAL AND RECYCLING

23.1 Unit disconnection

Disconnection operations must be effected by a qualified technician, who must follow the dispositions provided in this manual into the section "*residual risks*".

Before the disconnection of the unit the following materials (if any) must be recovered:

- the refrigerant gas;
- brine mixtures from the hydraulic circuit;
- the compressors lubricant oil;
- avoid spillage or leakage into the environment.



All decommissioning operations must be carried out by authorised personnel in accordance with the national legislation in force in the country of destination.

Pending decommissioning and disposal, the machine can also be stored outdoors, provided that the unit has the electrical and hydraulic circuits intact and closed.



During recovery operations it is important to pay a great attention to avoid damages to people or environmental pollution.



During dismantlement phase the fan, the coil, the motor (if they are still usable) can be recovered in specialized centres.



The antifreeze liquid must be stored in appropriate containers according to the law.



Recover and dispose of materials according to national laws in force.

The structure and the various components, if not usable, must be demolished and subdivided according to their nature; in particular steel and aluminum present in high quantities in the unit.

All materials must be recovered or disposed of in compliance with the relevant national law.

- In the following table you can find the materials employed to build the unit, even those which are present in its components:

Material type	Employment	Q.ty in relation to weight	Presence
Rolled metal	baseframe- panels fan- electric motor	HIGH	ALWAYS
Aluminium	case- electric motor's structure- coils dampers- droplet separators	HIGH	ALWAYS
Copper	coils- motor	MEDIUM	ALWAYS
Polyurethane	panels	HIGH	OPTIONAL
Mineral wood	panels- sound attenuators	HIGH	OPTIONAL
Gummy material	gaskets- rubber shock absorber antivibration joints	LOW	ALWAYS
Nylon	handles- hinges- claps panelblocks	LOW	ALWAYS

In order to better assist its customers and users of its equipment, the Company will be obliged if any changes in unit property are communicated by simply giving:

- serial number or construction number of the unit;
- new user's name and address;
- new unit location in case of change in installation address.

23.2 RAEE Directive (EU only)



- The RAEE Directive requires that the disposal and recycling of electrical and electronic equipment must be managed through a specific collection, in appropriate centres, separate from mixed urban waste.
- The user is obliged not to dispose of the equipment, at the end of its working life, as urban waste, but to comply with Directive 2012/19/EU at European level and with Legislative Decree 49/2014 at national level.
- Units covered by the RAEE Directive are identified by the symbol shown above.
- Manufacturer can supply additional information on request, in particular it will indicate the reference certification body according to RAEE.

This image shows a full page of blank, lined paper. It features approximately 28 horizontal blue or grey lines spaced evenly apart, typical of notebook paper. The lines extend across the entire width of the page, leaving small margins at the top and bottom. There are no vertical lines, text, or other markings on the page.



VORTICE INDUSTRIAL S.r.l. si riserva il diritto di apportare tutte le varianti migliorative ai prodotti in corso di vendita.
VORTICE INDUSTRIAL S.r.l. reserves the right to make improvements to products at any time and without prior notice.
VORTICE INDUSTRIAL S.r.l. se réserve le droit d'apporter toutes les variations afin d'améliorer ses produits en cours de commercialisation.
VORTICE INDUSTRIAL S.r.l. behält sich vor, alle eventuellen Verbesserungsänderungen an den Produkten des Verkaufsangebots vorzunehmen.
VORTICE INDUSTRIAL S.r.l. se reserva el derecho a hacer cambios en los productos para su mejora en cualquier momento sin previo aviso.
VORTICE INDUSTRIAL S.r.l. 公司 股份有限公司 保留在产品销售期间进行产品改良的权利。

VORTICE GROUP COMPANIES

VORTICE S.p.A.
Strada Cerca, 2- frazione di Zoate
20067- Tribiano (MI)
Tel. +39 02-90.69.91
ITALY
vortice.com
postvendita@vortice-italy.com

VORTICE INDUSTRIAL S.r.l.
Via B. Brugnoli, 3
37063- Isola della Scala (VR)
Tel. +39 045 6631042
ITALY
vorticeindustrial.com
info@vorticeindustrial.com

VORTICE VENTILATION SYSTEM (CHANGZHOU) CO.LTD
Building 19, No.388 West Huanghe Road, Xinbei District,
Changzhou, Jiangsu Province CAP:213000
CHINA
vortice-china.com
vortice@vortice-china.com

VORTICE LIMITED
Beeches House-Eastern Avenue
Burton on Trent- DE 13 0BB
Tel. +44 1283-49.29.49
UNITED KINGDOM
vortice.ltd.uk
sales@vortice.ltd.uk

VORTICE LATAM S.A.
Bodega #6
Zona Franca Este Alajuela- Alajuela 20101
Tel. (+506) 2201 6934
COSTA RICA
vortice-latam.com
info@vortice-latam.com

CASALS VENTILACIÓN INDUSTRIAL IND., S.L.
Ctra. Camprodon, s/n
17860- Sant Joan de les Abadesses (Girona)
SPAIN
casals.com
ventilacion@casals.com